

5 CDC STEPS TO MINIMIZE MOLD AFTER SHUTDOWN

01 MAINTAIN INDOOR HUMIDITY AS LOW AS POSSIBLE, NOT EXCEEDING 50%.

02 AFTER SHUTDOWN AND BEFORE OCCUPANTS RETURN BUILDINGS SHOULD BE ASSESSED FOR ACCESS MOLD AND MOISTURE

03 AN HVAC SYSTEM THAT WAS NOT ACTIVE

DURING SHUTDOWN SHOULD BE OPERATED FOR 48-72 HRS BEFORE OCCUPANTS RETURN

04 AFTER BUILDING IS OPEN ROUTINELY CHECK HVAC SYSTEM

05 IF NO HVAC OPERATION AND MAINTENANCE PROGRAM IS IN PLACE, ONE SHOULD BE IMPLEMENTED